

[] | *heckert/en/fems/apps/App.TimeOfUseTariff.AncillaryCosts.png*

# FEMS App Time-Variable Grid Charges

Version:2025.10.1

Table of Contents

|                                                             |          |
|-------------------------------------------------------------|----------|
| <b>1. Introduction</b>                                      | <b>2</b> |
| <b>2. FEMS App Time-Variable Grid Charges — Description</b> | <b>2</b> |
| <b>3. Installing the app</b>                                | <b>2</b> |
| 3.1. Configuration . . . . .                                | 2        |
| <b>4. Contact us</b>                                        | <b>5</b> |

## 1. Introduction

### 1. Introduction

Dear customer,

Thank you for choosing the "FEMS App Time-Variable Grid Charges". You are welcome to send us your suggestions so that we can further improve the quality of our products.

### 2. FEMS App Time-Variable Grid Charges — Description

The FEMS App Time-Variable Grid Charges enables the use of time-variable grid charges in conjunction with a fixed, constant electricity tariff.

### 3. Installing the app

When you ordered the "FEMS App Time-Variable Grid Charges", you received a 16-digit license key. You can use this license key to redeem the app independently in the EMS App Center.

You can find instructions on how to proceed at this link: [here](#) .

The FEMS App Time-Variable Grid Charges must be configured during installation.

#### 3.1. Configuration



Image 1. Configuration of the app

1. Under *Maximum grid withdrawal by battery charging*, select the maximum battery charging.
2. Enter the gross price/kWh excluding grid charges under *Fixed electricity tariff*.
3. One of the predefined grid operators must be selected in the *Grid operator* drop-down menu:

Bitte wählen Sie Ihren Netzbetreiber aus:\*

- ☐ MIT Netz
- ☒ SH Netz
- ☐ Westnetz
- ☐ E.DIS
- ☐ Avacon
- ☐ LEW
- ☐ TE Netze
- ☐ Netze ODR
- ☐ Andere

CANCEL OK

Image 2. Selection of the grid operator



If your grid operator is not listed, you can add it yourself by selecting *Other* via the grid charges.

4. If you select *Other*, the time slots for the NT (low load tariff level) and for the HT (high load tariff level) must be entered in this window:

2025 Netzentgelte

Bitte Zeitfenster für NT (Niedriglasttarifstufe) und HT (Hochlasttarifstufe) eintragen. Für Zeiten ohne Eintrag gilt ST (Standardtarifstufe)

Preisartikel

|                       |   |          |
|-----------------------|---|----------|
| Hochlasttarifstufe    | 0 | Cent/kWh |
| Niedriglasttarifstufe | 0 | Cent/kWh |
| Standardtarifstufe    | 0 | Cent/kWh |

> Q1 - 01.01.2025 - 31.03.2025

> Q2 - 01.04.2025 - 30.06.2025

> Q3 - 01.07.2025 - 30.09.2025

> Q4 - 01.10.2025 - 31.12.2025

Image 3. Entering the low-load tariff level and the high-load tariff level

5. Click on *UPDATE APP*.
6. The following flat widget is now displayed in your FENECON Online Monitoring:




Image 4. Time-variable grid charges — Flat Widget

7. If you click on the widget *Time-variable grid charges* under the *HISTORY* tab, you will see the corresponding historical view:




Image 5. Time-variable grid charges — Historical view

8. This completes the configuration.

**4. Contact us**

For support, please contact:

Symphon-E Service

Service phone: +49 (0) 371 45 85 68 - 100

E-mail service: [symphon-e@heckert-solar.com](mailto:symphon-e@heckert-solar.com)