

Symphon·Ξ

Configuration Manual — Eastron

Version:2025.10.1

Table of Contents

1. Introduction 2

2. Product description 2

3. Integration via Modbus/RTU 2

 3.1. Configuration of the meter..... 2

 3.2. Configuration of the app..... 2

1. Introduction

1. Introduction

Dear customer,

The following configuration instructions describe the integration of Eastron meters in EMS. Please read these instructions carefully before starting the installation and configuration.

2. Product description

The following Eastron meters are compatible with EMS and can be integrated:

- SDM630 MODBUS-MID
- SDM72DM



The Eastron meters must be Modbus-capable.

3. Integration via Modbus/RTU

Installation of the meter and configuration according to the manufacturer's instructions.

3.1. Configuration of the meter

The following parameters must be set in the meter during integration:

- Baud rate: 9600
- Stop bit: 1
- Parity: None

The device address (Modbus ID) can be freely selected and must be individual for each meter.

3.2. Configuration of the app

When you ordered the [FEMS App Production and Consumption Meter](#), you received a 16-digit license key. You can use this license key to redeem the app independently in the EMS App Center. You can find instructions on how to do this at [here](#).

After entering the license key, the configuration interface appears.

[Konfigurationsoberfläche -- Einbindung über Modbus/RTU] | [/other/en/meters/eastron/Eastron_config_1.jpg](/other/en/meters/eastron/Eastron_config_1.jpg)

Image 1. Configuration interface — Integration via Modbus/RTU

1. Assign a suitable alias.
2. Specify the type of use as *Production Meter* or *Consumption Meter*.

3. Select the device to be measured under Modbus ID.
4. Select whether you want to invert the values.
5. Complete the setup by tapping/clicking on *INSTALL APP*.